



LEGEND
 RWA = ROAD WORK AHEAD
 RW500 = ROAD WORK 500'
 RWN = ROAD WORK NEXT XX MILES
 ERW = END ROAD WORK
 RPA = RAMP PAVING AHEAD

SEE STD E-100 FOR SIGN PLACEMENT
 NOT TO SCALE

CONSTRUCTION APPROACH SIGNING	PROJECT NAME: BOLTON - SO. BURLINGTON
	PROJECT NUMBER: AC IM 089-2(36)
	FILE NAME: /pave/04all4/p04all4.dgn
DESIGNED BY:	PLOT DATE: 17-MAY-2005
IPARM NAME: p04all4casl.i	DRAWN BY:
	CHECKED BY:
	SHEET 39 OF 76