



LEGEND
 RWA = ROAD WORK AHEAD
 RW500 = ROAD WORK 500 FEET
 RWN = ROAD WORK NEXT 16 MILES
 (16 MILES AT END OF RAMP "H")
 ERW = END ROAD WORK
 SRWA = SIDE ROAD WORK AHEAD
 SRW500 = SIDE ROAD WORK 500 FEET

LIST OF CONSTRUCTION SIGNS

LOCATION	RWA	RW500	ERW	RWN	SRWA	SRW500
I-89 NORTHBOUND						
BEGIN PROJECT	2	2		2		
END PROJECT			2			
I-89 SOUTHBOUND						
BEGIN PROJECT	2	2		2		
END PROJECT			2			
INTERCHANGE 10						
VT. ROUTE 100			2		4	4
INTERCHANGE 10 RAMPS			1	2		
INTERCHANGE 11						
VT. ROUTE 100			4		4	4
INTERCHANGE 11 RAMPS			2	1		
TOTALS	4	4	13	7	8	8

FOR ADDITIONAL INFORMATION SEE SHEET 17.

NOT TO SCALE

CONSTRUCTION APPROACH SIGNING SHEET 2	PROJECT NAME: WATERBURY-RICHMOND	
	PROJECT NUMBER: IM SURF (33)	
	FILE NAME: ...I2A178\...I2A178.dgn	PLOT DATE: 10-APR-2014 14:17
	PROJECT LEADER: M. FOWLER	DRAWN BY: PAVT MGMT
DESIGNED BY: PAVT MGMT	CHECKED BY: PAVT MGMT	
IPARM FILE NAME: I2A178_I8.i	SHEET 18 OF 19	