



- LEGEND**
- RWA = ROAD WORK AHEAD
  - RW500 = ROAD WORK 500 FEET
  - RWN = ROAD WORK NEXT 9 MILES
  - ERW = END ROAD WORK
  - SRWA = SIDE ROAD WORK AHEAD
  - SRW500 = SIDE ROAD WORK 500 FEET

FOR ADDITIONAL INFORMATION SEE SHEET 17.

**NOT TO SCALE**

<b>CONSTRUCTION APPROACH SIGNING SHEET 3</b>	PROJECT NAME: WATERBURY-RICHMOND	
	PROJECT NUMBER: IM SURF (33)	
	FILE NAME: ...I2A178\...I2A178.dgn	PLOT DATE: 10-APR-2014 14:17
	PROJECT LEADER: FOWLER	DRAWN BY: PVT. MGT.
DESIGNED BY: PVT. MGT.	CHECKED BY: PAVT MGMT	
IPARM FILE NAME: I2A178_19.i	SHEET 19 OF 19	