



- LEGEND**
- RWA = ROAD WORK AHEAD
  - RW500 = ROAD WORK IN 500 FEET
  - RWN = ROAD WORK NEXT (XX MILES)
  - ERW = END ROAD WORK
  - SRWA = SIDE ROAD WORK AHEAD
  - SRW500 = SIDE ROAD WORK 500 FEET
  - △ = PORTABLE CHANGEABLE MESSAGE SIGN
  - [Hatched Box] = WORK AREA
  - ← = DIRECTION OF TRAFFIC FLOW

SEE VAOT STANDARDS T-1, T-10, T-11 AND T-13 FOR SIGN PLACEMENT.  
 CONSTRUCTION APPROACH SIGNING SHALL BE PLACED AS NOT TO  
 INTERFERE WITH EXISTING TRAFFIC CONTROL DEVICES.  
 SEE COMPOSITE TRAFFIC NOTES SHEET.

**NOT TO SCALE**

PROJECT NAME: BERLIN-BARRE CITY	
PROJECT NUMBER: NH SURF(44)	
FILE NAME: I3B634/pvtmgt/pi3b634.dgn	PLOT DATE: 06-JUN-2014
PROJECT LEADER: J. HARRINGTON	DRAWN BY: PVT. MGT.
DESIGNED BY: PVT. MGT.	CHECKED BY: PVT. MGT.
CONSTRUCTION APPROACH SIGNING SHEET	SHEET 23 OF 64