



LEGEND

- RWA = ROAD WORK AHEAD
- RW500 = ROAD WORK IN 500 FEET
- RWN = ROAD WORK NEXT (XX MILES)
- ERW = END ROAD WORK
- SRWA = SIDE ROAD WORK AHEAD
- SRW500 = SIDE ROAD WORK 500 FEET
- △ = PORTABLE CHANGEABLE MESSAGE SIGN
- [Hatched Box] = WORK AREA
- ← = DIRECTION OF TRAFFIC FLOW

SEE VAOT STANDARDS T-1, T-10, T-11 AND T-13 FOR SIGN PLACEMENT.
 CONSTRUCTION APPROACH SIGNING SHALL BE PLACED AS NOT TO
 INTERFERE WITH EXISTING TRAFFIC CONTROL DEVICES.
 SEE COMPOSITE TRAFFIC NOTES SHEET.

PROJECT NAME: BERLIN-MONTPELIER	
PROJECT NUMBER: IM SURF(45)	
FILE NAME: I3a636/pvtmgt/p3a636_wrk.dgn	DATE: 06-JUN-2014
PROJECT LEADER: J. HARRINGTON	DRAWN BY: PVT. MGT.
DESIGNED BY: PVT. MGT.	CHECKED BY: PVT. MGT.
CONSTRUCTION APPROACH SIGNING SHEET	SHEET 39 OF 64