



LEGEND

- RWA = ROAD WORK AHEAD
- RW500 = ROAD WORK IN 500 FEET
- RWN = ROAD WORK NEXT (XX MILES)
- ERW = END ROAD WORK
- SRWA = SIDE ROAD WORK AHEAD
- SRW500 = SIDE ROAD WORK 500 FEET

△ = PORTABLE CHANGEABLE MESSAGE SIGN

▨ = WORK AREA

← = DIRECTION OF TRAFFIC FLOW

SEE VAOT STANDARDS T-1, T-10, T-11 AND T-12 FOR SIGN PLACEMENT.
 CONSTRUCTION APPROACH SIGNING SHALL BE PLACED AS NOT TO
 INTERFERE WITH EXISTING TRAFFIC CONTROL DEVICES.
 SEE CONSTRUCTION APPROACH SIGNING NOTES SHEET.

EXIT 20 - INTERCHANGE

PROJECT NAME: COLCHESTER-SWANTON	
PROJECT NUMBER: IM SURF(56)	
FILE NAME: pl6v071_wrk.dgn	PLOT DATE: 09-DEC-2016
PROJECT LEADER: M. FOWLER	DRAWN BY: B. KIPP
DESIGNED BY: B. KIPP	CHECKED BY: M. FOWLER
CONSTRUCTION APPROACH SIGNING SHEET 5 SHEET 49 OF 54	