



Attention of the Engineer is called to rock fill placed at the outlet of some culverts to prevent scour. This is to be a non-pay item.

Note
Sta. 5+70 to Sta. 6+5
Widen Shoulders on right with waste material.

CHANGE IN DESIGN
It was found necessary during construction to build a Cem. Rubble Masonry Ret. Wall on the left Sta. 3+80 to Sta. 4+40 with 6" Perf. C.G.M.P.B.C. 3rd Underdrain in front of it.

BM #1 SPIKE IN 10' ASH 12' RT OF STA 3+92 ELEV 500.00
 BM #2 SPIKE IN 14' BIRCH 21' RT OF STA. 8+20 ELEV 473.82
 BM #3 SPIKE IN ROOT OF 18' BIRCH 18' RT OF STA 11+05 ELEV 454.49

15+25
400' VC
416.00
SERIES NRS 160
SHEET 4 OF 16