



END WOOD GUIDE POSTS (MOD)
Sta. 276+00 Rr.

CONSTRUCT APPROACH
282+00 LT

CONSTRUCT DRIVES

CONSTRUCT TURNOUT
250+30 TO 281+20 LT.

LT	RT
282+50	282+03
283+25	283+20
285+00	283+72
286+20	284+00
	284+30
	287+80
	281+00
	286+20

Rev. PI 282+35.9
282+12.1

Survey
PI 281+30.0
282+10.7
Δ 34°18' RT
D 80'

B.M. #42
Elev 230.87

STA 289+32
END PROJECT
S 81(2)

STA 289+32
BEGIN PROJECT
S 81(3)

Rev. Curve
Δ 20°42' Lt
D 7'
R 819.0
T 149.6
L 235.7
E 13.5
Bank 1/2 per ft

B.M. #43
Elev 222.98

FRANKLIN
Proj. S No. 81(2)
Sheet 29 of 70