



**LEGEND**

- ERW = END ROAD WORK
- RW500 = ROAD WORK 500 FT
- RWA = ROAD WORK AHEAD
- SRWA = SIDE ROAD WORK AHEAD

LOCATION	ERW	RW500	RWA	SRWA
<b>VT ROUTE 14</b>				
BEGIN APPROACH	1	2	2	0
END APPROACH	1	2	2	0
SIDE APPROACH	3	0	0	5
TOTALS	5	4	4	5

**CONSTRUCTION APPROACH SIGNING**

NOT TO SCALE  
 SEE VTrans STANDARD E-100 & E-100A FOR SIGN PLACEMENT.  
 THIS WORK TO BE PAID FOR UNDER ITEM 641.10.

PROJECT NAME: BARRE TOWN PARK-AND-RIDE  
 PROJECT NUMBER: CMG PARK (24) S

FILE NAME: ...PlotFiles\09 approach.ptf PLOT DATE: 4/4/2006  
 PROJECT LEADER: GAS DRAWN BY: MBL  
 DESIGNED BY: SRZ CHECKED BY: GAS  
**CONSTRUCTION APPROACH SIGNS** SHEET 9 OF 14

