

Material will be placed upstream and downstream of the culvert as shown in the Plans.

Fill in voids in the stone with a mixture of fines from the existing stream bed material. Fill voids by hand tamping with metal tamping rods, plate compactors, and water pressure with a metal wand to reach between stones.

Once all material has been placed in the stream channel, the Contractor will slowly wet the stream to minimize the effects of the initial sediment pulse. Every attempt will be made to minimize the movement of sediment downstream of the site.

- xx. METHOD OF MEASUREMENT. The quantity of Special Provision (Natural Streambed Material) is incidental to the Contract.
- xx. BASIS OF PAYMENT. The accepted quantity of Special Provision (Natural Streambed Material) will be paid under the Lump Sum for WP 5.2.6.1 and WP 5.3.7.1 of the Contract. Payment will be full compensation for furnishing, transporting, handling, and placing the material specified and for furnishing all labor, tools, equipment, and incidentals necessary to complete the work.