



CONSTRUCTION APPROACH SIGNING

SEE STD. E-100 FOR SIGN PLACEMENT

LEGEND

RWA = ROAD WORK AHEAD
 RW500 = ROAD WORK 500 FEET
 EW = END WORK
 RWN = ROAD WORK NEXT 7 MILES

THE RESIDENT ENGINEER, AT HIS OR HER DISCRETION,
 MAY ELIMINATE CONSTRUCTION APPROACH SIGNING AT
 DEAD END LOCATIONS

NOTE:

I. PAYMENT FOR CONSTRUCTION SIGNING WILL BE MADE UNDER CONTRACT ITEM 64I.I0.

TEMPORARY CONSTRUCTION SIGNING	PROJECT NAME: CANAAN	PLOT DATE: 18-MAY-2009
	PROJECT NUMBER: STP SURF (7)	DRAWN BY: LOCKE
	FILE NAME: p07c292.dgn	CHECKED BY: PAVT MGMT
	PROJECT LEADER: DOMEY	SHEET 7 OF 7
	DESIGNED BY: LOCKE	
	p07c292+tp.l	