



CONSTRUCTION APPROACH SIGNING

SEE STD. E-100 FOR SIGN PLACEMENT

- LEGEND
- RWA = ROAD WORK AHEAD
 - RW500 = ROAD WORK 500 FEET
 - EW = END WORK
 - RWN = ROAD WORK NEXT 7 MILES

THE RESIDENT ENGINEER, AT HIS OR HER DISCRETION,
MAY ELIMINATE CONSTRUCTION APPROACH SIGNING AT
DEAD END LOCATIONS

NOTE:

- I. PAYMENT FOR CONSTRUCTION SIGNING WILL BE MADE UNDER CONTRACT ITEM 64I.I0.

TEMPORARY CONSTRUCTION SIGNING	PROJECT NAME: NORTON - CANAAN	PLOT DATE: 07-APR-2010
	PROJECT NUMBER: STP SURF (13)	DRAWN BY: LOCKE
	FILE NAME: p08cl56.dgn	CHECKED BY: PAVT MGMT
	PROJECT LEADER: DOMEY	SHEET 7 OF 11
	DESIGNED BY: LOCKE	
	p08cl56+cp.i	