



NOTES:

1. PREBORE HOLES FOR ALL LAG SCREWS AND HOOK BOLTS. HOLES FOR LAG SCREWS SHALL BE BORED WITH A BIT NOT LARGER THAN THE BODY OF THE SCREW AT THE BASE OF THE THREAD. SEE SPECIAL PROVISIONS FOR TYPE OF LAG SCREWS AND HOOK BOLTS REQUIRED.
2. THE JOINT BETWEEN ABUTTING TIMBER TIE SPACERS SHALL NOT BE PLACED ON A BRIDGE TIE.
3. NAIL EACH TIMBER SPACER BLOCK TO AT LEAST ONE BRIDGE TIE WITH 8" RING SHANK NAILS. SPACER BLOCKS SHALL BE CUT TO FIT WHERE INDICATED IN DECK PLAN.
4. ALL COSTS FOR THE COMPLETE TIMBER DECK SHALL BE INCLUDED IN ITEM 900.645, SPECIAL PROVISION (TIMBER DECK, RAILROAD BRIDGE), INCLUDING BRIDGE TIES, TIE SPACERS, TIE SPACER BLOCKS, HOOK BOLTS, LAG SCREWS, NAILS, AND ANY OTHER REQUIRED MATERIALS.

PROJECT NAME: DORSET	PLOT DATE: 4/10/2014
PROJECT NUMBER: WCRS(8)	DRAWN BY: J.W. GOLEK
FILE NAME: z08q224detaildeck.dgn	CHECKED BY: S.E. BURBANK
PROJECT LEADER: A.P. GUYETTE	SHEET 18 OF 33
DESIGNED BY: J.W. GOLEK	
DECK DETAILS	