



CONSTRUCTION APPROACH SIGNING

SEE STD. E-100 FOR SIGN PLACEMENT

LEGEND

RWA = ROAD WORK AHEAD
 RW500 = ROAD WORK 500 FEET
 EW = END WORK
 RWN = ROAD WORK NEXT 10 MILES

THE RESIDENT ENGINEER, AT HIS OR HER DISCRETION,
 MAY ELIMINATE CONSTRUCTION APPROACH SIGNING AT
 DEAD END LOCATIONS

NOTE:

I. PAYMENT FOR CONSTRUCTION SIGNING WILL BE MADE
 UNDER CONTRACT ITEM 64I.I0.

**TEMPORARY
 CONSTRUCTION
 SIGNING**

PROJECT NAME: BARRE TOWN - ORANGE
 PROJECT NUMBER: STP SURF (15)

FILE NAME: p09b038.dgn
 PROJECT LEADER: MARSHIA
 DESIGNED BY: LOCKE
 p09b038+tcp.i

PLOT DATE: 10-NOV-2011
 DRAWN BY: LOCKE
 CHECKED BY: PAVT MGMT
 SHEET 15 OF 24