



CONSTRUCTION APPROACH SIGNING

SEE STD. E-100 FOR SIGN PLACEMENT

- LEGEND
- RWA = ROAD WORK AHEAD
 - RW500 = ROAD WORK 500 FEET
 - EW = END WORK
 - RWN = ROAD WORK NEXT 3 MILES

THE RESIDENT ENGINEER, AT HIS OR HER DISCRETION,
MAY ELIMINATE CONSTRUCTION APPROACH SIGNING AT
DEAD END LOCATIONS

NOTE:
1. PAYMENT FOR CONSTRUCTION SIGNING WILL BE MADE
UNDER CONTRACT ITEM 641.10.

TEMPORARY CONSTRUCTION SIGNING	PROJECT NAME: GROTON - RYEGATE	PLOT DATE: 10-NOV-2011
	PROJECT NUMBER: STP SURF (16)	DRAWN BY: LOCKE
	FILE NAME: p09b038.dgn	CHECKED BY: PAVT MGMT
	PROJECT LEADER: MARSHIA	SHEET 22 OF 24
	DESIGNED BY: LOCKE	
	p09b040+tcp.i	