

Directional Drill approx. 630'
 1-4" sch 40 PVC and
 3-1 1/4" Innerduct with
 48" cover.

Start Directional Drill

Trench

30" X 42"
 Hand Hole


Use existing Bridge
 Brackets and Install
 2-4" Fiberglass Conduits
 across Bridge

Add 2-4" Fiberglass
 Conduits to Existing
 Bridge Hangers

2-4" Rigid Conduits
 concrete encased
 in excavation

Note: Datum is USGS Topography

- Legend:**
- Trench 1-4" PVC and 3-1 1/4" Innerduct
 - Directionally Drill 1-4" SDR 13.5 HDPE and 3-1 1/4" Innerduct Conduits

 ENGINEERS CONSTRUCTION, INC. P.O. BOX 2187 SOUTH BURLINGTON, VT 05407 (802) 683-6389		TITLE: FAIRPOINT COMMUNICATIONS Route 207 Highgate, Vermont	
		DRAWN BY: NKP	SCALE: 1" = 20'
CHECKED BY: AHP	DIV NO.:	RECORD LOCATION DRAWING	
APPROVED BY: AHP			REV: -