

28738	29156	LT	418	N	12.5	STEEL W-BEAM	FAIR	REMOVE BEFORE CONSTRUCTING SIDE SLOPES AND DELINEATE WITH BARRELS. INSTALL TEMPORARY GUARDRAIL IMMEDIATELY AFTER CONSTRUCTION OF SLOPES.	425
28738	29090	RT	352	N	14	STEEL W-BEAM	FAIR	REMOVE BEFORE CONSTRUCTING SIDE SLOPES AND DELINEATE WITH BARRELS	350
30208	30498	RT	290	N	13-16.5	STEEL W-BEAM	FAIR	REMOVE BEFORE CONSTRUCTING SIDE SLOPES AND DELINEATE WITH BARRELS	
30534	30762	RT	228	N	13.5-14	STEEL W-BEAM	FAIR	REMOVE BEFORE CONSTRUCTING SIDE SLOPES AND DELINEATE WITH BARRELS	50
30669	30819	LT	150	N	14-15	STEEL W-BEAM	FAIR	REMOVE BEFORE CONSTRUCTING SIDE SLOPES AND DELINEATE WITH BARRELS	
31145	31286	RT	141	N	12.5	STEEL W-BEAM	FAIR	REMOVE BEFORE CONSTRUCTING SIDE SLOPES AND DELINEATE WITH BARRELS	
31611	31727	LT	116	N	14	STEEL W-BEAM	FAIR	REMOVE BEFORE CONSTRUCTING SIDE SLOPES AND DELINEATE WITH BARRELS	
31640	31827	RT	187	N	15	STEEL W-BEAM	FAIR	REMOVE BEFORE CONSTRUCTING SIDE SLOPES AND DELINEATE WITH BARRELS. INSTALL TEMPORARY GUARDRAIL IMMEDIATELY AFTER CONSTRUCTION OF SLOPES.	200
33030	33278	LT	248	N	13.5	STEEL W-BEAM	FAIR	REMOVE BEFORE CONSTRUCTING SIDE SLOPES AND DELINEATE WITH BARRELS	
33057	33947	RT	890	N	14	STEEL W-BEAM	FAIR	REMOVE BEFORE CONSTRUCTING SIDE SLOPES AND DELINEATE WITH BARRELS. INSTALL TEMPORARY GUARDRAIL IMMEDIATELY AFTER CONSTRUCTION OF SLOPES.	900
33989	35085	RT	1096	N	14	STEEL W-BEAM	FAIR	REMOVE BEFORE CONSTRUCTING SIDE SLOPES AND DELINEATE WITH BARRELS. INSTALL TEMPORARY GUARDRAIL IMMEDIATELY AFTER CONSTRUCTION OF SLOPES.	1100
35192	35618	RT	426	N	14	STEEL W-BEAM	FAIR	REMOVE BEFORE CONSTRUCTING SIDE SLOPES AND DELINEATE WITH BARRELS. INSTALL TEMPORARY GUARDRAIL IMMEDIATELY AFTER CONSTRUCTION OF SLOPES.	425
36097	36361	RT	264	N	14	STEEL W-BEAM	FAIR	REMOVE BEFORE CONSTRUCTING SIDE SLOPES AND DELINEATE WITH BARRELS	
36609	37041	RT	432	N	14	STEEL W-BEAM	FAIR	REMOVE BEFORE CONSTRUCTING SIDE SLOPES AND DELINEATE WITH BARRELS	
Randolph - Route 12									
A+STA.									
0	82	RT	82	N	14	STEEL W-BEAM	FAIR	REMOVE BEFORE CONSTRUCTING SIDE SLOPES AND DELINEATE WITH BARRELS	
210	535	RT	325	N	14	STEEL W-BEAM	FAIR	REMOVE BEFORE CONSTRUCTING SIDE SLOPES AND DELINEATE WITH BARRELS. INSTALL TEMPORARY GUARDRAIL IMMEDIATELY AFTER CONSTRUCTION OF SLOPES.	325
2553	2678.5	RT	125.5	N	15	STEEL W-BEAM	FAIR	REMOVE BEFORE CONSTRUCTING SIDE SLOPES AND DELINEATE WITH BARRELS. INSTALL TEMPORARY GUARDRAIL IMMEDIATELY AFTER CONSTRUCTION OF SLOPES.	125
2570.5	2645.5	LT	75	N	16	STEEL W-BEAM	FAIR	REMOVE BEFORE CONSTRUCTING SIDE SLOPES AND DELINEATE WITH BARRELS. INSTALL TEMPORARY GUARDRAIL IMMEDIATELY AFTER CONSTRUCTION OF SLOPES.	75
6077	6539	RT	462	N	22.5	STEEL W-BEAM	GOOD	REMOVE BEFORE CONSTRUCTING SIDE SLOPES AND DELINEATE WITH BARRELS	
6327	6687	LT	360	N	22	STEEL W-BEAM	GOOD	REMOVE BEFORE CONSTRUCTING SIDE SLOPES AND DELINEATE WITH BARRELS	
7272	7447	RT	175	N	17	STEEL W-BEAM	GOOD	REMOVE BEFORE CONSTRUCTING SIDE SLOPES AND DELINEATE WITH BARRELS	
TOTAL =									5225

PROJECT NAME:	BETHEL-RANDOLPH	PLOT DATE:	4/23/2015
PROJECT NUMBER:	STP 2921(I)	DRAWN BY:	J. GOODALL
FILE NAME:	z10c244d01.dgn	CHECKED BY:	C. LATHROP
PROJECT LEADER:		CONST. OPER. TRF. PROT. PLAN SHEET 2	SHEET 23 OF 211