



Rev 20+07 L1
Begin Excavation & Removal of Road
Surfaces & Pavements

Rev 20+00 L1
Begin Paved Shoulder Transition

Banking Transition Diagram

D=7.30 Pt

FROM STA.	20+00	TO STA.	20+50
PROJECT	1990	DATE	10/10/90
DESIGNED BY	BRUNNEN	PLANNED	BRUNNEN
CHECKED BY	BRUNNEN	DATE	10/10/90