



①  
-  
P032  
TOE-BOARD

INSTALLATION PROCEDURES

- 1.) PLACE TOE-BOARD (P032) ON OUTSIDE EDGE OF PLATFORM, OVER DECK CLIP.
- 2.) LINE UP HOLES IN TOE-BOARD WITH THREADED STUD OF DECK CLIP.
- 3.) PLACE TOE-BOARD RETAINER (F011-REG) THROUGH HOLES IN TOE-BOARD, AND TIGHTEN TO THREADED STUD OF DECK CLIP.
- 4.) PLACE ANOTHER TOE-BOARD ON PLATFORM, FIT IT INTO PREVIOUS TOE-BOARD, AND REPEAT PROCEDURES 2 & 3.

NOTE: DECK CLIP MUST BE PREVIOUSLY INSTALLED WITH THE HOOK SHANK FACING THE OUTSIDE OF THE PLATFORM.

NOTE: PART NUMBERS IN PARENTHESES ARE SAFESPAN INTERNAL PART NUMBERS.

SHEET 1 OF 2

SAFESPAN, INC. IS THE MANUFACTURER OF A UNIQUE PROPRIETARY AND PATENTED MULTI-SPAN PLATFORM SYSTEM. US. PATENTS #5,730,248, 5,921,346, 6,003,634, 6,135,240, 6,138,793, 6,227,331, 6,264,002, 6,302,237, 6,386,319, & 6,523,644. AUSTRALIAN PATENT #720,795. OTHER INTERNATIONAL AND US. PATENTS PENDING. ANY ATTEMPT AT SYSTEM DUPLICATION IS A VIOLATION AND IS SUBJECT TO PENALTY UNDER LAW.

REV.	DATE	BY	REVISION DESCRIPTION



© COPYRIGHT 2012 SAFESPAN, INC.

DESIGNED BY: D.E.P.	CHECKED BY: A.W.T.	PHOENIX DEVELOPMENT	
DRAWN BY: D.J.L.	CHECKED BY: D.E.P.	ROUTE 2 BRIDGE OVER WINOOSKI BRIDGE	
DATE: 02-17-11	SCALE: NO SCALE	TOE-BOARD INSTALLATION	
S.S. PROJECT No: 1318111000	OWNERS PROJECT No: STP-RS 0284(11)	REV. :	JOB No. : 131811
		DWG. No. : 720	