



- LEGEND**
- RCA = ROAD CONSTRUCTION AHEAD
 - RC500 = ROAD CONSTRUCTION 500'
 - EC = END CONSTRUCTION
 - SRCA = SIDE ROAD CONSTRUCTION AHEAD
 - SRC500 = SIDE ROAD CONSTRUCTION 500'
 - RCN = ROAD CONSTRUCTION NEXT

CONSTRUCTION APPROACH SIGNING

SEE STANDARD E-100 FOR SIGN PLACEMENT.

LIST OF TOWN HIGHWAYS FOR CONSTRUCTION SIGNS

TOWN HIGHWAY NUMBER	ROAD CONST. AHEAD	END CONST.	OTHER
TH 2	1	1	-
TH 6	1	1	-
TH 24	1	1	-
TH 23	1	1	-
TH 44	1	1	-
TH 3	1	1	-
TH 21	1	1	-
TH 19	1	1	-
TH 16	1	1	-
TOTAL	9	9	-

CONSTRUCTION SIGN DETAIL SHEET	SURVEYED BY	N/A	DATE	N/A
	DRAWN BY	WBL	DATE	03/93
	SQUAD LEADER			
	DESIGN FILE NO.			
	IPARM FILE		DATE PLOTTED	
	PROJ. NAME	SHEFFIELD-GLOVER		
PROJ. NO.	STP 9419(1)S			
SHEET	10 OF	SHEETS		
HTA FILE: SHFSDTLS				

DATUM	
VERTICAL	N/A
HORIZONTAL	N/A