



CONSTRUCTION APPROACH SIGNING

SEE STANDARD E-100 FOR SIGN PLACEMENT.

LEGEND
 EW = END ROAD WORK
 RW500 = ROAD WORK 500'
 RWA = ROAD WORK AHEAD
 RWN = ROAD WORK NEXT 4 MILES

**ARCHIVED
ON CADD**

**CONSTRUCTION
APPROACH
SIGNING
SHEET**

SURVEYED BY N/A DATE N/A
 DRAWN BY PAVE DATE 1/95
 SQUAD LEADER N/A
 DESIGN FILE NO. /pave/93b080/pb080a.dgn
 IPARM FILE pb080acs.i DATE PLOTTED 23-MAR-2001
 PROJ. NAME DORSET-MT. TABOR-DANBY
 PROJ. NO. NH 9514(1) C/1
 SHEET 6 OF 6 SHEETS

DATUM
 VERTICAL N/A
 HORIZONTAL N/A