



**CONSTRUCTION APPROACH SIGNING**  
SEE STD. E-100 FOR SIGN PLACEMENT

LOCATION	RWA	ERW	RW500	RWN	OTHER
SQUIRREL HILL ROAD	1	1			
MAD TOM ROAD	1	1			
COOK ROAD	1	1			
GRIFFITH ROAD	1	1			
DEPOT STREET	2	2			
RAYMOND ROAD	1	1			
BEGINNING OF PROJECT	2	2	2	1	
END OF PROJECT	2	2	2	1	
TOTAL	11	11	4	2	

**LEGEND**  
 RWA = ROAD WORK AHEAD  
 RW500 = ROAD WORK 500 FT  
 ERW = END ROAD WORK  
 RWN = ROAD WORK NEXT 10 MILES

<b>CONSTRUCTION APPROACH SIGNING</b>	PROJECT: <b>DORSET-MT TABOR-DANBY</b>	PROJECT NO. : <b>NH 2132 (1) S</b>
	DESIGN FILE NAME: /pave/93b080a/pb080.dgn	PLOT DATE: 13-AUG-1999
	IPARM FILE NAME: pb080cas.1	SURVEY DATE: N/A
	SURVEYED BY: N/A	DRAWN BY: SJL
	SQUAD LEADER: JAV	SHEET: 19 OF 19