



CONSTRUCTION APPROACH SIGNING

SEE STD. E-100M FOR SIGN PLACEMENT

LEGEND
 EW = END WORK
 SRWA = SIDE ROAD WORK AHEAD
 SRW500 = SIDE ROAD WORK 500 FEET

LIST OF CONSTRUCTION SIGNS

TOWN HIGHWAY	EW	SRWA	SRW500
BEGIN PROJECT	2	4	4
TOTALS	2	4	4

DATUM
 VERTICAL N/A
 HORIZONTAL N/A

CONSTRUCTION APPROACH SIGNING	DESIGNED BY <u> BCE/PJM </u> DATE <u> 2-02 </u>
	DRAWN BY <u> C.E.A., INC. </u> DATE <u> 2-02 </u>
	DESIGN FILE NO. <u> /pave/00c050/pc050.dgn </u>
	PRF FILE <u> pc050cas </u> DATE <u> 18-AUG-2003 </u>
	PROJ. NAME <u> MAIDSTONE </u>
	PROJ. NO. <u> STP 2134(1)S </u>
SHEET 19 OF 65 SHEETS	