



**Oblong Counterweight Assembly  
Figure 9**

15. **Horizontal Torque Adjustment**

Oblong counterweights on cast iron or aluminum counterweights arms.  
Refer to figure 10, page 18.

**NOTE: If a sidewalk arm is being used, all torque adjustments must be made with the sidewalk arm support installed and the  $\beta$  sidewalk gate arm installed.**

Open the mechanism cover and place the gate in the horizontal position by operating the cam switch, C, to the test position. Once the gate rests in the horizontal position, press the reset button on the EGM and be certain that the green LED is lit.