



REVISED ABUTMENT #2 SECTION
SCALE: 1:50

NOTES:

1. REBAR MARK "A1606 @ 300" SHALL BE DRILLED AND GROUTED INTO WINGWALL #3 AT LEFT END OF ABUTMENT AS CALLED FOR IN OCT 2009 PLANS SHEET 20R OF 26.
2. AFTER THE SUPERSTRUCTURE IS SET THE TWO PRECAST APPROACH SLABS SHALL BE SET WITH THE 25 mm GAP AND THEN HOLES DRILLED INTO THE ABUTMENT STEM FOR THE 600 mm REBAR.

RIPTON FH 010-1(42)
VTRANS - SEPT. 9, 2010
BY S.FARNSWORTH