

**CON-SERV INC
STANDARD OPERATING PROCEDURE**

S.O.P. No 1006 **EFFECTIVE DATE:** January 1, 1979
DESCRIPTION: Preparation of laminated silicone hi-temp sheet (G-7) for bonding. **Q.C. APPRVD.:** *R.C.*
SHT. 1 **OF** 1
REVISED DATE: October 28, 1996

STEP	PROCEDURE	COMMENTS
1.	Abrade both sides of the sheet with a coarse paper with an oscillating hand sander. The surface should feel rough to the touch and glaze removed.	
2.	Wipe the surfaces with a clean rag and a solvent prior to applying adhesive.	

RECEIVED
 OK'D BY _____
 DEC 15 2006
 RESUBMIT _____ APPROVED
 BY _____ DATE 01-05-07

061 55