

CON-SERV INC
STANDARD OPERATING PROCEDURE

S.O.P. No 1004

EFFECTIVE DATE: January 1, 1979

DESCRIPTION:

Q.C. APPRVD: *RE*

Preparation of preformed fabric for bonding.

SHT. 1 OF 1

REVISED DATE: October 28, 1996

STEP	PROCEDURE	COMMENTS
1.	PRIOR TO APPLYING THE ADHESIVE, Wipe surface of preformed fabric with a solvent. Then with a stub-bristled paint brush apply Chemlok #7701 solvent. Let dry approximately 15 minutes.	<div data-bbox="466 1845 695 1988" style="text-align: right;"> <p>RECEIVED OK'D BY _____ DEC 15 2006 RESUBMIT _____ APPROVED ✓ BY _____ DATE 01-05-07</p> </div>

06355