



PHASE III CONTRACT LIMIT

POWER PLAN

1/4" = 1'-0"



- DEMOLITION NOTES:**
- 1 REMOVE EXISTING PANEL COMPLETE WITH FEEDER AND BRANCH CKT. CONDUIT AND WIRING BACK TO SOURCE.
 - 2 REMOVE EXISTING PANEL AND REPLACE WITH NEW AS SHOWN ON PLAN. CIRCUIT AS SHOWN ON NEW PANEL SCHEDULE DWG. E9 (PANEL 'PB')
 - 3 REMOVE EXISTING LIGHT FIXTURES COMPLETE WITH CONDUIT AND WIRING BACK TO SOURCE.
 - 4 REMOVE EXISTING SWITCHES AND RECEPTACLES AND REPLACE WITH NEW AS SHOWN ON PLANS.
 - 5 REMOVE RECEPTACLE FOR EXISTING A/C UNIT COMPLETE WITH CONDUIT AND WIRING BACK TO SOURCE.
 - 6 REMOVE EXISTING WRENCHLOD AND RE-ROUTE AROUND NEW DOOR. REMRE AS REQUIRED.
 - 7 DISCONNECT AND REMOVE EXISTING POWER WIRING. INSTALL NEW 2 SPEED STARTER AND WIRE TO NEW MOTOR AND EXISTING DISCONNECT. FURNISH & INSTALL NEW BRANCH CKT. TO NEW PANEL 'PE'.

	<p>Tolbach Engineering, Inc. Consulting Engineers 20 Kimball Ave., Suite 102, S. Burlington, VT 05403 (802) 688-4044</p>	<p>State of Vermont Department of State Buildings John Zampieri, Commissioner</p>	<p>Materials & Research Laboratory Berlin, Vt.</p> <p>PHASE III</p>
<p>Janson Design, Inc. FRED KERL, ARCHITECT P.O. BOX 55 - BOSTON ROAD, WATERBURGH, VT 05676 (802) 244-5800</p>		<p>PHASE III FLOOR PLAN</p> <p>FIRST FLOOR STATE HIGHWAY LAB</p>	
<p>DATE: 1-10-91 DWG. NO. E-7</p>			