



ABANDONMENT OF EXISTING SEPTIC TANKS
DO NOT BEGIN ABANDONMENT PROCEDURES UNTIL THE NEW SEWER SYSTEM HAS BEEN INSTALLED AND ACCEPTED. PLEASE DO NOT SERVICE AND CONNECTIONS FROM REST AREAS TRANSFERRED FROM THE EXISTING TO NEW SEWERS. PUMP SEPTICAGE FROM TANKS, DISCONNECT SEWER TO BE ABANDONED FROM TANK AND FILL WALL OPENINGS WITH SAND.
THIS WORK IS INCLUDED UNDER THE ITEM OF "TRANSFER TO NEW SYSTEM - SANITARY SEWER (628.42)"

NO.	DATE	REVISIONS	BY	CRD.
1	1/25/90	ADDED SURVEY INFO. # REV. MH NOS.		



engineering
planning
management
development



STATE OF VERMONT
AGENCY OF TRANSPORTATION
PLAN
SEWER CONNECTION
FOR INTERSTATE 89 REST AREAS
WILLISTON, VERMONT
R089-2(13)

DRAWN BY	DATE	CHECKED BY	PROJ. NO.
GPE/RAWU	AUG. 1989	1902	R88825
PROJ. ENG.		CKG	DRAW. NO. 7038

SHEET 5 OF 8