



I-91 SIGNAGE SCHEMATIC
NOT TO SCALE

NOTE:
OFFSETS ARE FROM EDGE OF PAVED SHOULDER
TO NEAR EDGE OF SIGN.
THESE SIGNS TO BE COVERED DURING CONSTRUCTION
AT THE DIRECTION OF THE RESIDENT ENGINEER.