



GENERAL NOTES:
FLASHING IS RECOMMENDED AT HEAD TRIM & SIDES OF ALL DOORS EXCEPT SIDES OF GARAGE OR DOORS.
FLASHING BY OTHERS.
DO NOT LET WEIGHT OF LOGS BEAR ON WINDOW OR DOOR UNIT.

CAUTION:
NORTHEASTERN RECOMMENDS SEALING WITH BACKER ROD & CAULKING AS SHOWN HOWEVER, IF SPRAY FOAM INSULATION IS USED TO SEAL AT DOORS OR WINDOWS READ MANUFACTURER'S INSTALLATION PROCEDURES. APPLY ONLY A SMALL BEAD OF SPRAY FOAM AND DO NOT ATTEMPT TO FILL THE ENTIRE SPACE. SPRAY FOAM EXPANDS GREATLY AND COULD CAUSE ABNORMAL PRESSURE ON JAMBS RESTRICTING OPERATION OF MOVING PARTS. SPRAY FOAM INSULATION BY OTHERS.

AT ROUGH OPENING, INSTALL BACKER ROD & CAULKING SEAL. FILL ALL REMAINING SPACES WITH FIBERGLASS INSULATION BEFORE INSTALLING TRIM.
SEE MANUFACTURER'S INSTALLATION INSTRUCTIONS FOR ADDITIONAL INFORMATION ON ASSEMBLY OF GARAGE OVERHEAD DOORS. INSTRUCTIONS INCLUDED WITH DR. DOOR HARDWARE PACKAGE.
DETAILS ON THIS SHEET ARE GENERAL AND MAY NOT APPLY TO ALL BUILDINGS.



© 1993 by NLH Inc.

NO.	REVISION	DATE	BY	CHK

DRN MG COOPER
 CAD [Signature]
 PROJECT NAME: DOOR INSTALLATION
 IN LOG WALLS
 DATE: JAN. 1, 1995
 SCALE: AS NOTED
 SHEET NO: D-2