

INDEX OF SHEETS

1-1	Title Sheet	281	5-8	Three Cable Guard Rail - Steel Posts-Typ & Spacing	42,207.0	4
2-1	General Sheet	282	5-9	Steel Posts-Typ & Spacing	42,207.0	4
3-1	Vertical Curves	283	5-10	Project and Boundary Markers	3,400.0	4
4-1	Summary of Quantities	284	5-11	Details of Wide Flange Beam Bridges	1,200.0	4
5-1	Drainage Sheets	285	5-12	Details of Wide Flange Beam Bridges	1,200.0	4
6-1	Particular Details	286	5-13	Details of Wide Flange Beam Bridges	1,200.0	4
7-1	Plan and Profile	287	5-14	Aluminum Bridge Decking Details	1,200.0	4
8-1	Bridge Section 20 Scale	288	5-15	Cross Sections - Mainline	1,200.0	4
9-1	Bridge Section 30 Scale	289	5-16	Cross Sections - Sags	1,200.0	4
10-1	Bridge Section 40 Scale	290	5-17	Cross Sections - T-1	1,200.0	4
11-1	Bridge Section 50 Scale	291	5-18	Cross Sections - T-2	1,200.0	4
12-1	Bridge Section 60 Scale	292	5-19	Cross Sections - T-3	1,200.0	4
13-1	Bridge Section 70 Scale	293	5-20	Cross Sections - T-4	1,200.0	4
14-1	Bridge Section 80 Scale	294	5-21	Cross Sections - T-5	1,200.0	4
15-1	Bridge Section 90 Scale	295	5-22	Cross Sections - T-6	1,200.0	4
16-1	Bridge Section 100 Scale	296	5-23	Cross Sections - T-7	1,200.0	4
17-1	Bridge Section 110 Scale	297	5-24	Cross Sections - T-8	1,200.0	4
18-1	Bridge Section 120 Scale	298	5-25	Cross Sections - T-9	1,200.0	4
19-1	Bridge Section 130 Scale	299	5-26	Cross Sections - T-10	1,200.0	4
20-1	Bridge Section 140 Scale	300	5-27	Cross Sections - T-11	1,200.0	4
21-1	Bridge Section 150 Scale	301	5-28	Cross Sections - T-12	1,200.0	4
22-1	Bridge Section 160 Scale	302	5-29	Cross Sections - T-13	1,200.0	4
23-1	Bridge Section 170 Scale	303	5-30	Cross Sections - T-14	1,200.0	4
24-1	Bridge Section 180 Scale	304	5-31	Cross Sections - T-15	1,200.0	4
25-1	Bridge Section 190 Scale	305	5-32	Cross Sections - T-16	1,200.0	4
26-1	Bridge Section 200 Scale	306	5-33	Cross Sections - T-17	1,200.0	4
27-1	Bridge Section 210 Scale	307	5-34	Cross Sections - T-18	1,200.0	4
28-1	Bridge Section 220 Scale	308	5-35	Cross Sections - T-19	1,200.0	4
29-1	Bridge Section 230 Scale	309	5-36	Cross Sections - T-20	1,200.0	4
30-1	Bridge Section 240 Scale	310	5-37	Cross Sections - T-21	1,200.0	4
31-1	Bridge Section 250 Scale	311	5-38	Cross Sections - T-22	1,200.0	4
32-1	Bridge Section 260 Scale	312	5-39	Cross Sections - T-23	1,200.0	4
33-1	Bridge Section 270 Scale	313	5-40	Cross Sections - T-24	1,200.0	4
34-1	Bridge Section 280 Scale	314	5-41	Cross Sections - T-25	1,200.0	4
35-1	Bridge Section 290 Scale	315	5-42	Cross Sections - T-26	1,200.0	4
36-1	Bridge Section 300 Scale	316	5-43	Cross Sections - T-27	1,200.0	4
37-1	Bridge Section 310 Scale	317	5-44	Cross Sections - T-28	1,200.0	4
38-1	Bridge Section 320 Scale	318	5-45	Cross Sections - T-29	1,200.0	4
39-1	Bridge Section 330 Scale	319	5-46	Cross Sections - T-30	1,200.0	4
40-1	Bridge Section 340 Scale	320	5-47	Cross Sections - T-31	1,200.0	4
41-1	Bridge Section 350 Scale	321	5-48	Cross Sections - T-32	1,200.0	4
42-1	Bridge Section 360 Scale	322	5-49	Cross Sections - T-33	1,200.0	4
43-1	Bridge Section 370 Scale	323	5-50	Cross Sections - T-34	1,200.0	4
44-1	Bridge Section 380 Scale	324	5-51	Cross Sections - T-35	1,200.0	4
45-1	Bridge Section 390 Scale	325	5-52	Cross Sections - T-36	1,200.0	4
46-1	Bridge Section 400 Scale	326	5-53	Cross Sections - T-37	1,200.0	4
47-1	Bridge Section 410 Scale	327	5-54	Cross Sections - T-38	1,200.0	4
48-1	Bridge Section 420 Scale	328	5-55	Cross Sections - T-39	1,200.0	4
49-1	Bridge Section 430 Scale	329	5-56	Cross Sections - T-40	1,200.0	4
50-1	Bridge Section 440 Scale	330	5-57	Cross Sections - T-41	1,200.0	4
51-1	Bridge Section 450 Scale	331	5-58	Cross Sections - T-42	1,200.0	4
52-1	Bridge Section 460 Scale	332	5-59	Cross Sections - T-43	1,200.0	4
53-1	Bridge Section 470 Scale	333	5-60	Cross Sections - T-44	1,200.0	4
54-1	Bridge Section 480 Scale	334	5-61	Cross Sections - T-45	1,200.0	4
55-1	Bridge Section 490 Scale	335	5-62	Cross Sections - T-46	1,200.0	4
56-1	Bridge Section 500 Scale	336	5-63	Cross Sections - T-47	1,200.0	4
57-1	Bridge Section 510 Scale	337	5-64	Cross Sections - T-48	1,200.0	4
58-1	Bridge Section 520 Scale	338	5-65	Cross Sections - T-49	1,200.0	4
59-1	Bridge Section 530 Scale	339	5-66	Cross Sections - T-50	1,200.0	4
60-1	Bridge Section 540 Scale	340	5-67	Cross Sections - T-51	1,200.0	4
61-1	Bridge Section 550 Scale	341	5-68	Cross Sections - T-52	1,200.0	4
62-1	Bridge Section 560 Scale	342	5-69	Cross Sections - T-53	1,200.0	4
63-1	Bridge Section 570 Scale	343	5-70	Cross Sections - T-54	1,200.0	4
64-1	Bridge Section 580 Scale	344	5-71	Cross Sections - T-55	1,200.0	4
65-1	Bridge Section 590 Scale	345	5-72	Cross Sections - T-56	1,200.0	4
66-1	Bridge Section 600 Scale	346	5-73	Cross Sections - T-57	1,200.0	4
67-1	Bridge Section 610 Scale	347	5-74	Cross Sections - T-58	1,200.0	4
68-1	Bridge Section 620 Scale	348	5-75	Cross Sections - T-59	1,200.0	4
69-1	Bridge Section 630 Scale	349	5-76	Cross Sections - T-60	1,200.0	4
70-1	Bridge Section 640 Scale	350	5-77	Cross Sections - T-61	1,200.0	4
71-1	Bridge Section 650 Scale	351	5-78	Cross Sections - T-62	1,200.0	4
72-1	Bridge Section 660 Scale	352	5-79	Cross Sections - T-63	1,200.0	4
73-1	Bridge Section 670 Scale	353	5-80	Cross Sections - T-64	1,200.0	4
74-1	Bridge Section 680 Scale	354	5-81	Cross Sections - T-65	1,200.0	4
75-1	Bridge Section 690 Scale	355	5-82	Cross Sections - T-66	1,200.0	4
76-1	Bridge Section 700 Scale	356	5-83	Cross Sections - T-67	1,200.0	4
77-1	Bridge Section 710 Scale	357	5-84	Cross Sections - T-68	1,200.0	4
78-1	Bridge Section 720 Scale	358	5-85	Cross Sections - T-69	1,200.0	4
79-1	Bridge Section 730 Scale	359	5-86	Cross Sections - T-70	1,200.0	4
80-1	Bridge Section 740 Scale	360	5-87	Cross Sections - T-71	1,200.0	4
81-1	Bridge Section 750 Scale	361	5-88	Cross Sections - T-72	1,200.0	4
82-1	Bridge Section 760 Scale	362	5-89	Cross Sections - T-73	1,200.0	4
83-1	Bridge Section 770 Scale	363	5-90	Cross Sections - T-74	1,200.0	4
84-1	Bridge Section 780 Scale	364	5-91	Cross Sections - T-75	1,200.0	4
85-1	Bridge Section 790 Scale	365	5-92	Cross Sections - T-76	1,200.0	4
86-1	Bridge Section 800 Scale	366	5-93	Cross Sections - T-77	1,200.0	4
87-1	Bridge Section 810 Scale	367	5-94	Cross Sections - T-78	1,200.0	4
88-1	Bridge Section 820 Scale	368	5-95	Cross Sections - T-79	1,200.0	4
89-1	Bridge Section 830 Scale	369	5-96	Cross Sections - T-80	1,200.0	4
90-1	Bridge Section 840 Scale	370	5-97	Cross Sections - T-81	1,200.0	4
91-1	Bridge Section 850 Scale	371	5-98	Cross Sections - T-82	1,200.0	4
92-1	Bridge Section 860 Scale	372	5-99	Cross Sections - T-83	1,200.0	4
93-1	Bridge Section 870 Scale	373	5-100	Cross Sections - T-84	1,200.0	4
94-1	Bridge Section 880 Scale	374	5-101	Cross Sections - T-85	1,200.0	4
95-1	Bridge Section 890 Scale	375	5-102	Cross Sections - T-86	1,200.0	4
96-1	Bridge Section 900 Scale	376	5-103	Cross Sections - T-87	1,200.0	4
97-1	Bridge Section 910 Scale	377	5-104	Cross Sections - T-88	1,200.0	4
98-1	Bridge Section 920 Scale	378	5-105	Cross Sections - T-89	1,200.0	4
99-1	Bridge Section 930 Scale	379	5-106	Cross Sections - T-90	1,200.0	4
100-1	Bridge Section 940 Scale	380	5-107	Cross Sections - T-91	1,200.0	4
101-1	Bridge Section 950 Scale	381	5-108	Cross Sections - T-92	1,200.0	4
102-1	Bridge Section 960 Scale	382	5-109	Cross Sections - T-93	1,200.0	4
103-1	Bridge Section 970 Scale	383	5-110	Cross Sections - T-94	1,200.0	4
104-1	Bridge Section 980 Scale	384	5-111	Cross Sections - T-95	1,200.0	4
105-1	Bridge Section 990 Scale	385	5-112	Cross Sections - T-96	1,200.0	4
106-1	Bridge Section 1000 Scale	386	5-113	Cross Sections - T-97	1,200.0	4
107-1	Bridge Section 1010 Scale	387	5-114	Cross Sections - T-98	1,200.0	4
108-1	Bridge Section 1020 Scale	388	5-115	Cross Sections - T-99	1,200.0	4
109-1	Bridge Section 1030 Scale	389	5-116	Cross Sections - T-100	1,200.0	4
110-1	Bridge Section 1040 Scale	390	5-117	Cross Sections - T-101	1,200.0	4
111-1	Bridge Section 1050 Scale	391	5-118	Cross Sections - T-102	1,200.0	4
112-1	Bridge Section 1060 Scale	392	5-119	Cross Sections - T-103	1,200.0	4
113-1	Bridge Section 1070 Scale	393	5-120	Cross Sections - T-104	1,200.0	4
114-1	Bridge Section 1080 Scale	394	5-121	Cross Sections - T-105	1,200.0	4
115-1	Bridge Section 1090 Scale	395	5-122	Cross Sections - T-106	1,200.0	4
116-1	Bridge Section 1100 Scale	396	5-123	Cross Sections - T-107	1,200.0	4
117-1	Bridge Section 1110 Scale	397	5-124	Cross Sections - T-108	1,200.0	4
118-1	Bridge Section 1120 Scale	398	5-125	Cross Sections - T-109	1,200.0	4
119-1	Bridge Section 1130 Scale	399	5-126	Cross Sections - T-110	1,200.0	4
120-1	Bridge Section 1140 Scale	400	5-127	Cross Sections - T-111	1,200.0	4
121-1	Bridge Section 1150 Scale	401	5-128	Cross Sections - T-112	1,200.0	4
122-1	Bridge Section 1160 Scale	402	5-129	Cross Sections - T-113	1,200.0	4
123-1	Bridge Section 1170 Scale	403	5-130	Cross Sections - T-114	1,200.0	4
124-1	Bridge Section 1180 Scale	404	5-131	Cross Sections - T-115	1,200.0	4
125-1	Bridge Section 1190 Scale	405	5-132	Cross Sections - T-116	1,200.0	4
126-1	Bridge Section 1200 Scale	406	5-133	Cross Sections - T-117	1,200.0	4
127-1	Bridge Section 1210 Scale	407	5-134	Cross Sections - T-118	1,200.0	4
128-1	Bridge Section 1220 Scale	408	5-135	Cross Sections - T-119	1,200.0	4
129-1	Bridge Section 1230 Scale	409	5-136	Cross Sections - T-120	1,200.0	4
130-1	Bridge Section 1240 Scale	410	5-137	Cross Sections - T-121	1,200.0	4
131-1	Bridge Section 1250 Scale	411	5-138	Cross Sections - T-122	1,200.0	4
132-1	Bridge Section 1260 Scale	412	5-139	Cross Sections - T-123	1,200.0	4
133-1	Bridge Section 1270 Scale	413	5-140	Cross Sections - T-124	1,200.0	4
134-1	Bridge Section 1280 Scale	414	5-141	Cross Sections - T-125	1,200.0	4
135-1	Bridge Section 1290 Scale	415	5-142	Cross Sections - T-126	1,200.0	4
136-1	Bridge Section 1300 Scale	416	5-143	Cross Sections - T-127	1,200.0	4
137-1	Bridge Section 1310 Scale	417	5-144	Cross Sections - T-128	1,200.0	4
138-1	Bridge Section 1320 Scale	418	5-145	Cross Sections - T-129	1,200.0	4
139-1	Bridge Section 1330 Scale	419	5-146	Cross Sections - T-130	1,200.0	4
140-1	Bridge Section 1340 Scale	420	5-147	Cross Sections - T-131	1,200.0	4
141-1	Bridge Section 1350 Scale	421	5-148	Cross Sections - T-132	1,200.0	4
142-1	Bridge Section 1360 Scale	422	5-149	Cross Sections - T-133	1,200.0	4
143-1	Bridge Section 1370 Scale	423	5-150	Cross Sections - T-134	1,200.0	4
144-1	Bridge Section 1380 Scale	424	5-151	Cross Sections - T-135	1,200.0	4
145-1	Bridge Section 1390 Scale	425	5-152	Cross Sections - T-136	1,200.0	4
146-1	Bridge Section 1400 Scale	426	5-153	Cross Sections - T-137	1,200.0	4
147-1	Bridge Section 1410 Scale	427	5-154	Cross Sections - T-138	1,200.0	4
148-1	Bridge Section 1420 Scale	428	5-155	Cross Sections - T-139	1,200.0	4
149-1	Bridge Section 1430 Scale	429	5-156	Cross Sections - T-140	1,2	