



## Functions

<b>Arrow keys</b>	<ul style="list-style-type: none"> <li>To scroll through a menu.</li> <li>To scroll through the values of a parameter.</li> <li>To select a submenu.</li> </ul>
<b>Enter key</b>	<ul style="list-style-type: none"> <li>To enter a menu, a submenu or an item within a submenu.</li> <li>To edit a value for a parameter and confirm.</li> </ul>
<b>Escape key</b>	<ul style="list-style-type: none"> <li>To exit the menu or submenu.</li> </ul>
<b>Next key</b>	<ul style="list-style-type: none"> <li>To proceed to the next detection line or zone.</li> </ul>
<b>Previous key</b>	<ul style="list-style-type: none"> <li>To move to the previous detection zone or line.</li> </ul>
<b>Add key</b>	<ul style="list-style-type: none"> <li>To add a detection zone or line.</li> </ul>
<b>Del key</b>	<ul style="list-style-type: none"> <li>To delete a detection zone or line.</li> </ul>
<b>Direction key</b>	<ul style="list-style-type: none"> <li>To make a zone direction sensitive.</li> </ul>
<b>Help key</b>	<ul style="list-style-type: none"> <li>To display help text for an item.</li> </ul>
<b>Output number key</b>	<ul style="list-style-type: none"> <li>To assign an output number to a detection zone.</li> </ul>
<b>Operate key</b>	<ul style="list-style-type: none"> <li>To put the board in operation mode.</li> </ul>
<b>Modify key</b>	<ul style="list-style-type: none"> <li>To change settings while starting from the last saved settings for all parameters.</li> </ul>
<b>Edit key</b>	<ul style="list-style-type: none"> <li>To change settings while starting from default values for all parameters.</li> </ul>