



Functions

Arrow keys	<ul style="list-style-type: none"> • To scroll through a menu. • To scroll through the values of a parameter. • To select a submenu.
Enter key	<ul style="list-style-type: none"> • To enter a menu, a submenu or an item within a submenu. • To edit a value for a parameter and confirm.
Escape key	<ul style="list-style-type: none"> • To exit the menu or submenu.
Next key	<ul style="list-style-type: none"> • To proceed to the next detection line or zone.
Previous key	<ul style="list-style-type: none"> • To move to the previous detection zone or line.
Add key	<ul style="list-style-type: none"> • To add a detection zone or line.
Del key	<ul style="list-style-type: none"> • To delete a detection zone or line.
Direction key	<ul style="list-style-type: none"> • To make a zone direction sensitive.
Help key	<ul style="list-style-type: none"> • To display help text for an item.
Output number key	<ul style="list-style-type: none"> • To assign an output number to a detection zone.
Operate key	<ul style="list-style-type: none"> • To put the board in operation mode.
Modify key	<ul style="list-style-type: none"> • To change settings while starting from the last saved settings for all parameters.
Edit key	<ul style="list-style-type: none"> • To change settings while starting from default values for all parameters.