



tsc
MODEL
CUB
200

CUB
200

MODEL
200

204

S9 LS10 LS11 LS12 LS13 LS14 LS15 LS16
12 12 12 12 12 12 12 12

AC-
CTRL
START
DELAY
AC-
CTRL
FL
REV
AC-
FL
ODT
DOW
DOOR

FR2 FR3 FR4 FR6

K1
CMU
SENSORS
K2
24V
CONTROL

GB3
24V
DND

113 114 115 116 117 118 119 120 121 122

145 146 147 148 149 150 151 152 153 154 155 156 157 158 159 160

A 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 122 B
125 126 127 128 129 130 131 132

CABINET
LIGHT
ON
OFF

CONNECT
TO EARTH
GROUNDING