

**CON-SERV INC  
STANDARD OPERATING PROCEDURE**

S.O.P. No 1009

EFFECTIVE DATE: January 1, 1979

**DESCRIPTION:**

Q.C. APPRVD.: *RE*

Test check on etching solution.

SHT. 1 OF 1

REVISED DATE: October 28, 1996

STEP	PROCEDURE	COMMENTS
1.	Fill the plastic tube to the 4 ml. mark with the solution to be tested.	
2.	Add 2 to 3 drops of the M.O. Indicator.	
3.	Slowly add Turco Scale Test Solution dropwise until, after shaking, the color changes from red-pink to orange-yellow. Count the number of drops.	Hold plastic dropper bottle vertically.
4.	The approximate 3 by volume of N.O. #1 is 1/3 of the number of drops of test solution added.	

RECEIVED  
 CK'D BY \_\_\_\_\_  
 DEC 15 2006  
 RESUBMIT APPROVED:   
 BY \_\_\_\_\_ DATE 01-09-07

05855