


VT. ROUTE 9
MM 3.152 = STA. 5+072.652
END PROJECT NH 2225(I)S
BEGIN PROJECT NH 2202(I)S

VT. ROUTE 9
MM 5.901 = STA. 9+496.739
END PROJECT NH 2202(I)S

U.S. ROUTE 7
MM 3.413 = STA. 5+492.691
END PROJECT NH 2202(I)S

U.S. ROUTE 7
MM 2.876 = STA. 4+628.473
BEGIN PROJECT NH 2202(I)S



U.S. ROUTE 7 LIST OF TOWN HIGHWAYS FOR CONSTRUCTION SIGNS			
TOWN HIGHWAY NUMBER	ROAD WORK AHEAD	END ROAD WORK	OTHER
BEGIN PROJECT	2	1	2 - RW500 1 - RWN
T-430	1	1	
T-342	-	1	
T-338	-	1	
T-332	1	1	
T-336	1	1	
T-5	1	1	
T-326	1	1	
END PROJECT	2	1	2 - RW500 1 - RWN
TOTAL	9	9	6

VERMONT ROUTE 9 LIST OF TOWN HIGHWAYS FOR CONSTRUCTION SIGNS			
TOWN HIGHWAY NUMBER	ROAD WORK AHEAD	END ROAD WORK	OTHER
T-912	1	1	
T-2 NORTH	1	1	
T-2 SOUTH	1	1	
T-2	1	1	
T-910	1	1	
T-320	1	1	
T-394	1	1	
T-396	1	1	
T-324	1	1	
T-398	1	1	
T-7	1	1	
T-404	1	1	
T-406	1	1	
T-416	1	1	
T-330	1	1	
T-340	1	1	
T-438	-	1	

VERMONT ROUTE 9 LIST OF TOWN HIGHWAYS FOR CONSTRUCTION SIGNS			
TOWN HIGHWAY NUMBER	ROAD WORK AHEAD	END ROAD WORK	OTHER
T-442 NORTH	-	1	
T-442 SOUTH	1	-	
T-430	1	1	
T-342	1	1	
T-360	1	1	
T-476	1	1	
T-3	1	1	
T-374	1	1	
T-486	1	1	
T-384	1	1	
ROCKWOOD ST.	1	1	
T-504	1	1	
T-6	1	1	
T-508	1	1	
END PROJECT	2	1	2 - RW500 1 - RWN
TOTAL	31	31	3

SIGN LEGEND

- RWA = ROAD WORK AHEAD
- RW500 = ROAD WORK 500 FEET
- ERW = END ROAD WORK
- RWN = ROAD WORK NEXT 3 MILES

CONSTRUCTION APPROACH SIGNING

SEE STD. E-100M FOR ADDITIONAL SIGN PLACEMENT

NOTE:

THE RESIDENT ENGINEER AT HIS OR HER DISCRETION SHALL ELIMINATE CONSTRUCTION APPROACH SIGNS FOR DEAD END/NO OUTLET TOWN HIGHWAYS OR TOWN HIGHWAYS THAT CONNECT ON BOTH SIDES OF THE PROJECT.

CONSTRUCTION APPROACH SIGNING DETAIL SHEET

SURVEYED BY N/A DATE N/A
 DRAWN BY J.A.R. DATE 4/01
 SQUAD LEADER T.P.K.
 DESIGN FILE NO. pave/99d156/pdl56.dgn
 IPARM FILE pdl56cas.i DATE 27 NOV-2005 10:47:27
 PROJ. NAME BENNINGTON
 PROJ. NO. NH 2202(I)S
 SHEET 80 OF 108 SHEETS

DATUM
 VERTICAL N/A
 HORIZONTAL N/A