


VT. ROUTE 9
 MM 3.152 = STA. 5+072.652
 END PROJECT NH 2225(I)S
 BEGIN PROJECT NH 2202(I)S

VT. ROUTE 9
 MM 0.000 = STA. 0+000.000
 BEGIN PROJECT NH 2225(I)S



CONSTRUCTION APPROACH SIGNING

SEE STD. E-100M FOR ADDITIONAL SIGN PLACEMENT

SIGN LEGEND

- RWA = ROAD WORK AHEAD
- RW500 = ROAD WORK 500 FEET
- ERW = END ROAD WORK
- SRWA = SIDE ROAD WORK AHEAD
- SRW500 = SIDE ROAD WORK 500 FEET
- RWN = ROAD WORK NEXT 3 1/4 MILES

LIST OF TOWN HIGHWAYS FOR CONSTRUCTION SIGNS

TOWN HIGHWAY NUMBER	ROAD WORK AHEAD	END ROAD WORK	OTHER
BEGIN PROJECT	2	1	2 - RW500 1 - RWN
T-72	1	1	
T-40	1	1	
T-42	1	1	
T-83	1	1	
T-74	1	1	
T-46	1	1	
T-39	1	1	
T-12	1	1	
T-12	1	1	
TOTAL	11	10	3

NOTES:

1. THE RESIDENT ENGINEER AT HIS OR HER DISCRETION SHALL ELIMINATE CONSTRUCTION APPROACH SIGNING ON DEAD END/NO OUTLET TOWN HIGHWAYS.
2. THE CONTRACTOR SHALL CONTACT JAN MEILHEDE OF THE NEW YORK STATE DEPARTMENT OF TRANSPORTATION AT (518) 286-2301 PRIOR TO INSTALLING CONSTRUCTION APPROACH SIGNS IN NEW YORK

CONSTRUCTION APPROACH SIGNING SHEET

SURVEYED BY N/A DATE N/A
 DRAWN BY C.A.K. DATE 12/00
 SQUAD LEADER T.P.K.
 DESIGN FILE NO. /pave/99d156/pd156.dgn
 IPARM FILE pb054cas.1 DATE PLOTTED \$DATE\$
 PROJ. NAME BENNINGTON
 PROJ. NO. NH 2225(I)S
 SHEET 108 OF 108 SHEETS

DATUM
 VERTICAL N/A
 HORIZONTAL N/A