



SHRUB PLANTING POCKET CROSS-SECTION IN
"GRUBBING" MATERIAL OVER STONE FILL
NOT TO SCALE



TREE PLANTING ON SLOPES DETAIL
NOT TO SCALE



SHRUB PLANTING ON SLOPES DETAIL
NOT TO SCALE

LANDSCAPE NOTES:

1. ALL PLANTING LOCATIONS SHALL BE STAKED OUT PRIOR TO PLANTING. THE ENGINEER IN CONSULTATION WITH THE AGENCY'S CONSULTANT FIELD NATURALIST MAY ADJUST THE STAKES AS NEEDED PRIOR TO INSTALLATION. ADJUSTMENTS TO THE PLANTING DESIGN AND LAYOUT MAY BE REQUIRED BASED UPON ACTUAL FIELD CONDITIONS.
2. ALL LANDSCAPE CONSTRUCTION ACTIVITIES SHALL BE CONFINED TO WITHIN THE LIMITS OF DISTURBANCE AS IDENTIFIED ON THE PLANS OR AS OTHERWISE DIRECTED BY THE ENGINEER.
3. LANDSCAPE BACKFILL SHALL CONSIST OF ONE HALF SCREENED TOPSOIL, ONE QUARTER COMPOST, AND ONE QUARTER NATIVE MATERIAL AS APPROVED BY THE ENGINEER. TAMP TO REMOVE AIR POCKETS AND WATER THOROUGHLY IMMEDIATELY AFTER PLANTING. TREES TO RECEIVE A MINIMUM OF 10 GALLONS AT EACH WATERING, TWICE WEEKLY DURING THE ESTABLISHMENT PERIOD. SHRUBS TO RECEIVE A MINIMUM OF 5 GALLONS AT EACH WATERING, TWICE WEEKLY DURING THE ESTABLISHMENT PERIOD. UNSUITABLE NATIVE MATERIAL SHALL BE REPLACED WITH IMPORTED APPROVED TOPSOIL AS DIRECTED BY ENGINEER.
4. MYCORRHIZA SHALL BE APPLIED TO ALL TREE AND SHRUB PLANTINGS PER MANUFACTURER'S INSTRUCTION AND FURNISHED IN ACCORDANCE WITH SUBSECTION 755.07.
5. A 3-4" LAYER OF BARK MULCH AROUND PLANTINGS SHALL BE AGED, DOUBLE SHREDDED AND IN ITS NATURAL UNDYED STATE. EXTEND MULCH LAYER 6" BEYOND PLANT PIT TO PREVENT DRYING AIR FROM REACHING ROOT BALL. TAPER MULCH TO BASE OF TRUNK FLARE AS WELL. AVOID STOCKPILING MULCH FOR LONG PERIODS TO PREVENT ANAEROBIC CONDITION AND BUILD UP OF TOXINS.
6. ALL TREES SHALL BE GROWN AS TREE FORMS AND TRAINED IN THE NURSERY TO A SINGLE STRAIGHT TRUNK.
7. SIDE SLOPE PLANTING IN STONE FILL: DIG INDIVIDUAL 3' DIA. PLANTING POCKETS, ONE FOR EACH SHRUB AS LOCATED ON THE PLANTING PLANS.
8. LANDSCAPE BACKFILL SHALL BE PLACED FOR TREES AT TIME OF FINAL GRADING SO TREES CAN BE PLANTED AT A LATER DATE AND MATERIAL WILL BE IN PLACE.
9. PLACE TREE IN HOLE SO THAT MAIN ORDER ROOTS ARE AT OR SLIGHTLY ABOVE FINISHED GRADE. REMOVE ALL EXCESS SOIL ON TOP OF THE ROOT FLARE AND ABOVE MAIN ORDER ROOTS. AVOID PLANTING TOO DEEP. ONCE IN THE PLANTING HOLE, REMOVE TWINE AND BURLAP FROM TOP 1/2 OF BALL; IF SYNTHETIC, REMOVE COMPLETELY. CUT WIRE BASKETS AND REMOVE ENTIRE SIDES.

PROJECT NAME: BRATTLEBORO
PROJECT NUMBER: BRO 1442(35)

FILE NAME: z10j062details_plants.dgn
PROJECT LEADER: S.E. BURBANK
DESIGNED BY: E.A. FIALA
PLANTING DETAILS

PLOT DATE: 10/14/2013
DRAWN BY: E.A. FIALA
CHECKED BY: S.E. BURBANK
SHEET 22 OF 68