



DEMO NOTES:

- 1 REMOVE DUCT SHOWN HATCHED
- 2 REMOVE DUCT SHOWN HATCHED - AS REQUIRED TO INSTALL NEW TRANSITION
- 3 REMOVE EXISTING TRANSITION SHOWN HATCHED
- 4 EXISTING DUCT TO REMAIN AS IS
- 5 REMOVE EXISTING FLUE & PART INDUCER ASSEMBLY ON ROOF ABOVE FURNACE CURB TO REMAIN AS IS AND TO BE RE-USED IN NEW WORK
- 6 REMOVE EXISTING FURNACE FLUE, WIRING, & FUEL LINES - EXISTING TRAPEZE CHANNEL HANGERS ARE TO BE RE-USED
- 7 REMOVE EXISTING THERMOSTATS AND BASES - NEW THERMOSTATS TO BE MOUNTED IN THE SAME LOCATIONS - EXISTING THERMOSTAT WIRING MAY BE RE-USED PROVIDED IT MEETS CURRENT CODES
- 8 REMOVE EXISTING WOOD FURNACE, POWER WIRING, FUEL PIPE, & CONTROLS - EXISTING PAD AND DUCT HANGERS TO BE RE-USED
- 9 EXISTING MASONRY CHIMNEY TO FOOTING AT GRADE LEVEL - FOOTING TO BE RE-USED FOR NEW MASONRY CHIMNEY
- 10 REMOVE EXISTING FUEL LINES - SUPPLY BACK TO PUMP OUTLET AND RETURN TO SLEEVE AT SLAB - PREP PIPES FOR RECONNECTION UNDER NEW WORK (SEE FUEL PIPING SCHEMATIC ON M1)