






MS # 803










MOBIL STATION



US 7 NORTH




HIGHGATE COMMONS

-  VIDEO CAMERA
-  CONTROL BOX
-  MAST ARM
-  VIDEO DETECTION
-  PULL BOX
-  =
-  =


US 7 SOUTH

NOT TO SCALE




MS # 803



MOBIL STATION



US 7 NORTH







US 7 SOUTH

HIGHGATE COMMONS

NOT TO SCALE

D
I
A
G
R
A
M



TIMING





G =
Y =

G =
Y =

G =
Y =

G =
Y =

D
I
A
G
R
A
M



TIMING


G =
Y =

G =
Y =


G =
Y =

G =
Y =

PROTECTED
TURNS



PERMITTED
TURNS
PEDESTRIAN



CYCLE LENGTH, C = _____ S



PROPERTY OF
VT. AGENCY OF TRANS.
MAINTENANCE DIV.
IN EMERGENCY CALL
DST TRANS OFFICE
24H-365D
NIGHTS & WEEKENDS, 824-5983
INTERSECTION NO. MS-803

PROPERTY OF :

VT. AGENCY OF TRANS.
MAINTENANCE DIV.

IN EMERGENCY CALL :

DIST. TRANS. OFFICE

524-5926

NIGHTS & WEEKENDS : 524-5993

INTERSECTION NO. MS - 803

DANGER


115 VOLTS A.C.

WARNING

DO NOT OPERATE
CABINET WITHOUT
CMU / MMU


ON


7-6-2004
13:00



SECUNOLITE







Rev. G

BUS INTERFACE UNIT

POWER ON
TRANSMIT
VALID DATA

Autoscope®
Terra Access Point
ECONOLITE

POWER
MVP 1-16

SELECT 1-3

IO



DET. SW MODULE
DET 1-16

LM 622t (x4)
SENS, FREQ, DET, FLT

ECONOLITE (x4)

B. I. U. DETECTOR #1

L3 2A	DLY	L1	L7	L5 4B	DLY	L15	L13	PREDPTOR EVP#3	PREDPTOR EVP#5	DETECTOR SWITCHING MODULES
L4 4A		L2	L8 8A	L6 5		L16	L14	EVP#4	EVP#6	





Mobil
3.59/gal
3.79/gal
3.89/gal
3.99/gal

WELCOME TO
SAINT ALBANS TOWN
VERMONT

35



Highway Commons

PROANE REFILL \$15.99

Benjamin Moore

1844 N.C. NORTH CAROLINA



CO



Boon
LIVE CAR



SUNOCO

Moose

15 MIN
CYLINDERS
FILLED
with
meras

Dirty
Carpets?
Rug Doctor

366

384



PLAQUE INFORMATION



12.5" / 21"
48KSI / 5GA
10" / 39" / 7GA



ONLY









11/17/2014
48X51/2008
11/15/116A

V
VRECMONT

14.0" / 32'
48KSI / 219"
11" / 50' / 7GA



ONLY ↑ ONLY

NO PARKING

Travel Information ←

...YON ...
...
Credit Approval

Mobil

SALE



Mobil

POOL SHOCK \$19.99

Mobil

RIGHT LANE
MUST
SIGN FIRST
LEFT LANE
MUST
SIGN LAST

Highgate Commons
COMMERCIAL, RETAIL, OFFICE BUILDINGS
Restaurants, Specialty Shops

SALE









12.5" / 2"
48KSE / 5GA
10" / 40" / 7GA



PUCHON HARDWARE

Mobil

GTM Electric Supply






HARDWARE

Mobil

GTM Electric Supply

SEARS





Mobil

Clearance 13'6"

GTM Electric Supply

N & GARDEN
SPECTACULAR

Self



Mobil

Clearance 13'6"

GTM Electric Supply

SEARS

CS • LAWN & GARDEN • TG 21'9"

AUBUCHON



1107200
REHEZTGA
17587TGA

0



11.0" / 32'
48KSI / 7GA
7" / 24' / 7GA

Coordination Patterns

```

-----
Pattern 1
Cycle Length . . . 64  COS . . . . . 111
Offset . . . . . 0
Vehicle Permissive . . [1] 0 [2] 0
Vehicle Perm 2 Displacement 0 Phase Reservice. . NO
Splits: Phase 1- 14 2- 25 3- 11 4- 14
          Phase 5- 14 6- 25 7- 11 8- 14
          Phase 9- 0 10- 0 11- 0 12- 0 Split Sum: 0
Split Extension/Ring [1] 0 [2] 0
Split Demand Pattern [1] 0 [2] 0
XRT Pattern. . . 0
Phase Number: 1 2 3 4 5 6 7 8 9 10 11 12
Coord Phases . . . X . . . X . . . . .
Veh Recall . . . . . . . . . . .
Veh Max Recall . . . . . . . . . . .
Ped Recall . . . . . . . . . . .
Veh Omit . . . . . . . . . . .
Alt Sequence . . A: . B: . C: X D: . E: . F: .
-----
    
```

```

-----
Pattern 2
Cycle Length . . . 72  COS . . . . . 211
Offset . . . . . 0
Vehicle Permissive . . [1] 0 [2] 0
Vehicle Perm 2 Displacement 0 Phase Reservice. . NO
Splits: Phase 1- 14 2- 24 3- 11 4- 23
          Phase 5- 11 6- 27 7- 11 8- 23
          Phase 9- 0 10- 0 11- 0 12- 0 Split Sum: 0
Split Extension/Ring [1] 0 [2] 0
Split Demand Pattern [1] 0 [2] 0
XRT Pattern. . . 0
Phase Number: 1 2 3 4 5 6 7 8 9 10 11 12
Coord Phases . . . X . . . X . . . . .
Veh Recall . . . . . . . . . . .
Veh Max Recall . . . . . . . . . . .
Ped Recall . . . . . . . . . . .
Veh Omit . . . . . . . . . . .
Alt Sequence . . A: . B: . C: X D: . E: . F: .
-----
    
```

```

-----
Pattern 3
Cycle Length . . . 66  COS . . . . . 311
Offset . . . . . 0
Vehicle Permissive . . [1] 0 [2] 0
Vehicle Perm 2 Displacement 0 Phase Reservice. . NO
Splits: Phase 1- 15 2- 26 3- 11 4- 14
          Phase 5- 14 6- 27 7- 11 8- 14
          Phase 9- 0 10- 0 11- 0 12- 0 Split Sum: 0
Split Extension/Ring [1] 0 [2] 0
Split Demand Pattern [1] 0 [2] 0
XRT Pattern. . . 0
Phase Number: 1 2 3 4 5 6 7 8 9 10 11 12
Coord Phases . . . X . . . X . . . . .
Veh Recall . . . . . . . . . . .
Veh Max Recall . . . . . . . . . . .
Ped Recall . . . . . . . . . . .
Veh Omit . . . . . . . . . . .
Alt Sequence . . A: . B: . C: X D: . E: . F: .
-----
    
```


NIC Program Steps

Step	Program	Step Begins	Pattern	Override
1	1	0600	1	NO
2	1	0900	2	NO
3	1	1530	3	NO
4	1	1830	2	NO
5	2	0600	1	NO
6	2	0900	2	NO
7	2	1530	3	NO
8	2	1800	2	NO
9	3	0600	1	NO
10	3	0900	2	NO
11	3	1530	3	NO
12	3	1800	2	NO

TOD Program Steps

Step 5 Program 1 Step Begins 2200

Flash. X Dimming Enable.
 Red Rest Alt Veh Extension
 Spare 5. Det Log Enable.
 Spare 3. Spare 4
 Type 0 Dly Enable. Spare 2
 Det Diag Plan. 0

Phase Number

	1	2	3	4	5	6	7	8	9	10	11	12
Max 2 Enable
Max 3 Enable
Veh Recall
Veh Max Recall
Ped Recall
Cond Service Inhibit.
Phase Omit
Special Function

A B C D E F

Alt Sequence

Step 6 Program 2 Step Begins 0600

Flash. Dimming Enable.
 Red Rest Alt Veh Extension
 Spare 5. Det Log Enable.
 Spare 3. Spare 4
 Type 0 Dly Enable. Spare 2
 Det Diag Plan. 0

Phase Number

	1	2	3	4	5	6	7	8	9	10	11	12
Max 2 Enable
Max 3 Enable
Veh Recall
Veh Max Recall
Ped Recall
Cond Service Inhibit.
Phase Omit
Special Function

A B C D E F

Alt Sequence

TOD Program Steps

 Step 7 Program 2 Step Begins 0900

Flash. Dimming Enable.
 Red Rest Alt Veh Extension
 Spare 5. Det Log Enable.
 Spare 3. Spare 4
 Type 0 Dly Enable. . . Spare 2
 Det Diag Plan. . . . 0

Phase Number

	1	2	3	4	5	6	7	8	9	10	11	12
Max 2 Enable	X	X	X	X	X	X	X	X
Max 3 Enable
Veh Recall
Veh Max Recall
Ped Recall
Cond Service Inhibit.
Phase Omit
Special Function

A B C D E F

Alt Sequence

Step 8 Program 2 Step Begins 1530

Flash. Dimming Enable.
 Red Rest Alt Veh Extension
 Spare 5. Det Log Enable.
 Spare 3. Spare 4
 Type 0 Dly Enable. . . Spare 2
 Det Diag Plan. . . . 0

Phase Number

	1	2	3	4	5	6	7	8	9	10	11	12
Max 2 Enable
Max 3 Enable	X	X	X	X	X	X	X	X
Veh Recall
Veh Max Recall
Ped Recall
Cond Service Inhibit.
Phase Omit
Special Function

A B C D E F

Alt Sequence

TOD Program Steps

 Step 11 Program 3 Step Begins 0600

Flash. Dimming Enable.
 Red Rest Alt Veh Extension
 Spare 5. Det Log Enable.
 Spare 3. Spare 4
 Type 0 Dly Enable. . . Spare 2
 Det Diag Plan. . . . 0

Phase Number

	1	2	3	4	5	6	7	8	9	10	11	12
Max 2 Enable
Max 3 Enable
Veh Recall
Veh Max Recall
Ped Recall
Cond Service Inhibit.
Phase Omit
Special Function

Alt Sequence A B C D E F

Step 12 Program 3 Step Begins 0900

Flash. Dimming Enable.
 Red Rest Alt Veh Extension
 Spare 5. Det Log Enable.
 Spare 3. Spare 4
 Type 0 Dly Enable. . . Spare 2
 Det Diag Plan. . . . 0

Phase Number

	1	2	3	4	5	6	7	8	9	10	11	12
Max 2 Enable	X	X	X	X	X	X	X	X
Max 3 Enable
Veh Recall
Veh Max Recall
Ped Recall
Cond Service Inhibit.
Phase Omit
Special Function

Alt Sequence A B C D E F

TOD Program Steps

 Step 13 Program 3 Step Begins 1530

Flash. Dimming Enable.
 Red Rest Alt Veh Extension
 Spare 5. Det Log Enable.
 Spare 3. Spare 4
 Type 0 Dly Enable. . . Spare 2
 Det Diag Plan. . . . 0

Phase Number

	1	2	3	4	5	6	7	8	9	10	11	12
Max 2 Enable
Max 3 Enable	X	X	X	X	X	X	X	X
Veh Recall
Veh Max Recall
Ped Recall
Cond Service Inhibit.
Phase Omit
Special Function

A B C D E F

Alt Sequence

Step 14 Program 3 Step Begins 1800

Flash. Dimming Enable.
 Red Rest Alt Veh Extension
 Spare 5. Det Log Enable.
 Spare 3. Spare 4
 Type 0 Dly Enable. . . Spare 2
 Det Diag Plan. . . . 0

Phase Number

	1	2	3	4	5	6	7	8	9	10	11	12
Max 2 Enable	X	X	X	X	X	X	X	X
Max 3 Enable
Veh Recall
Veh Max Recall
Ped Recall
Cond Service Inhibit.
Phase Omit
Special Function

A B C D E F

Alt Sequence

TOD Program Steps

Step 15 Program 3 Step Begins 2200

Flash.	X	Dimming Enable.	
Red Rest	Alt Veh Extension	
Spare 5.	Det Log Enable.	
Spare 3.	Spare 4	
Type 0 Dly Enable.	Spare 2	
Det Diag Plan.	0		

	Phase Number											
	1	2	3	4	5	6	7	8	9	10	11	12
Max 2 Enable
Max 3 Enable
Veh Recall
Veh Max Recall
Ped Recall
Cond Service Inhibit.
Phase Omit
Special Function

Alt Sequence	A	B	C	D	E	F						
------------------------	---	---	---	---	---	---	--	--	--	--	--	--
